

SHARPER IMAGE®

SMARTPHONE BATTERY BACKUP WITH FLASHLIGHT

Item No. 204455

User's Manual



Thank you for purchasing the Sharper Image Smartphone Battery Backup. This device is sure to come in handy for emergency power and light. Please take a moment to read this guide and save it for future reference.

SPECIFICATIONS

Capacity:	5200mAh
Rated input:	DC 5V-1A
Rated output:	DC 5V-1A
Size:	4.25" L x 1.8" W x 0.9" H
Charging time:	0~20 hours
Protection function:	Microcomputer intelligent protection
Working temperature:	-10°C to 45°C
Working humidity:	65% +/- 20%

CHARGING THE SMARTPHONE BATTERY BACKUP WITH FLASHLIGHT

To charge the device, use the supplied cable. Plug it into the INPUT port on one side. Then plug the other end into a computer USB port. The LED light will begin blinking blue during charging:

LED 1 = 25%
LED 2 = 50%
LED 3 = 75%
LED 4 = 100%

CHARGING A SMARTPHONE

- Connect your USB charging cable to the Smartphone Battery Backup with Flashlight.
- Then, plug the other end into your phone.
- The Blue LED light will turn on during the charging process.

NOTE: Please pay attention to your smartphone's battery level during the charging time.

USING THE LED FLASHLIGHT

- Press and hold the On/Off button for 2 seconds to turn the flashlight ON.
- Press and hold the On/Off button for 2 seconds to turn the flashlight OFF.
- Double-click the On/Off button to close all functions (charging for device and LED flashlight).
- Click the button again to activate the smartphone charging feature.

TROUBLE SHOOTING

1. The power level of the Smartphone Battery Backup with Flashlight is too low. Recharge the device as soon as possible.
2. Your smartphone might have incompatible voltage with the Smartphone Battery Backup with Flashlight. Consult your smartphone manual.
3. The cable connection might be loose. Please re-connect the charge cord and make sure the connection is firm and steady.

SPECIAL TIPS

- Always use the proper charging cable and charging port for your device.
- Do not charge the Smartphone Battery Backup with Flashlight and use it to charge your smartphone at the same time.
- Unplug the Smartphone Battery

Backup with Flashlight after it has finished charging.

- Unplug the Smartphone Battery Backup with Flashlight when you are not using it.
- To keep the Smartphone Battery Backup with Flashlight in top working order, please charge for 8 hours at least every two months.

NOTE: It is normal for the Smartphone Battery Backup with Flashlight to become warm during charging. It will gradually cool down to room temperature after fully charged.

SAFETY WARNINGS

- DO NOT throw the Smartphone Battery Backup with Flashlight into a fire or try to heat it up. It might burn, explode or release toxic gas.
- DO NOT connect the positive and negative poles together.
- DO NOT store this device with other metallic materials.
- DO NOT try to open or break the case, as this could cause damage or injury and also void the warranty.
- DO NOT use this device if you notice it is leaking, heating itself, out of shape, causing a foul odor or showing any other abnormal phenomenon.

WARRANTY / CUSTOMER SERVICE

Sharper Image branded items purchased from SharperImage.com include a 1-year limited replacement warranty. If you have any questions not covered in this guide, you may call our Customer Service department at 1 (877) 210-3449. Customer Service agents are available Monday through Friday, 9:00 a.m. to 6:00 p.m. ET.

SHARPER IMAGE®

The Sharper Image® name and logo are registered trademarks.
Manufactured and marketed by Camelot SI, LLC under license.
©Sharper Image All Rights Reserved.