


# SHARPER IMAGE®

## GIANT PIANO MAT

Item No. 204980

Owner's Manual



Thank you for purchasing the Sharper Image Giant Piano Mat. Please take a moment to read this Owner's Manual and store it for future reference.

### FEATURES

- Easy-to-use electronic instrument
- Touch-sensitive keys
- Dual speakers
- 9 electronic instrument tones
- 10 built-in melodies
- Folds for easy storage and travel
- On/Off switch
- LED indicator light
- Adjustable volume
- Connects to an MP3 player or other external audio source [3.5mm audio cable included]
- Cordless and battery operated [requires 4 AA batteries, not included]
- Ages 3+

### DESCRIPTION OF BUTTONS

- Press PLAY to begin playing live music. Use the keys to tap out a melody or make up your own songs.
- Press RECORD to enter recording mode. You will hear a brief tone and see the LED turn on. This indicates that the device is recording.



The device will stop recording automatically after 80 notes. Please be aware that if you press Record a second time, the device will erase your current recording and start a new recording.

- Press PLAYBACK to listen to your recorded music.
- Press DEMO to hear 10 built-in melodies. Use the black keys to change selections.
- Press TONE to change the musical instrument tone as follows: Piano > Vibraphone > Harp > Trumpet > Saxophone > Accordion > Violin > Guitar

### MP3 MODE

Connect your smartphone, tablet or MP3 player to the console with the included 3.5mm audio cable. While your device is connected the Giant Piano Mat, all of the piano keys are still functional, so you can play along with the music!

### SAFETY WARNINGS

- This toy is recommended for Ages 3+, with adult supervision.
- Do not mix old and new batteries.
- If you will not be using the Giant Piano Mat for a long period of time, please remove the batteries.
- Keep batteries out of the reach of children at all times.
- Do not use a knife, scissor or any sharp instrument to jab or cut the Giant Piano Mat.

## WARRANTY / CUSTOMER SERVICE

Sharper Image branded items purchased from SharperImage.com include a 1-year limited replacement warranty. If you have any questions not covered in this guide, please call Customer Service at 1 (877) 210-3449.

## **SHARPER IMAGE®**

The Sharper Image® name and logo are registered trademarks.

Manufactured and marketed by Camelot SI, LLC under license.

@Sharper Image All Rights Reserved.