


SHARPER IMAGE®

Battery Heated Gloves
Item No. 206112

HOW TO CHARGE

Connect batteries to the charger and plug the charger into the AC outlet. NOTE: Fully charge batteries before each use. Charge time is 4-5 hours.




Red Light - Battery is Charging
Green Light - Battery is Fully Charged



The battery connects via the cable in the zippered pocket on the palm side of the glove, and tucks away inside.


SIZE GUIDE: CARE

- INSTRUCTIONS:
Hand wash only
(remove batteries first) and hang to dry.
- XS: 7"-7.5"
 - S: 8"-8.5"
 - M: 9"-9.5"
 - L: 10"-10.5"
 - XL: 11"-11.5"



The easy-access temperature controller is as simple as the press of a button, and is designed to be used without removing your gloves.

To turn on/off, press and hold for two seconds.



When first turned on, the glove will default to High.

High/Red =
2-3 hours of heat



HIGH

Medium/Yellow =
4 hours of heat



MEDIUM

Low/Green =
5-5.5 hours of heat



LOW

To change the temperature, click the button to cycle through the heat settings.

WARRANTY/CUSTOMER SERVICE

Sharper Image branded items purchased from SharperImage.com include a 1-year limited replacement warranty. For Customer Service, please call 1 (877) 210-3449.